

## HOW TO FIT BUCKET SEATS



1. Place seat cover over back of seat and pull down-make sure front panel is square on the front of the seat.



2. Push the centre tie ring through the middle of the seat, enabling it to be pulled through from behind.



3. pull seat cover forward and neatly position the front and side panels down the base of the seat.



4. smooth out seat cover and pull the front tie under the seat. Ensure the centre back seam is straight.



5. Make sure all clips are in position. Clip together and pull for tension.

## HOW TO FIT REAR SEATS

1. Remove both back and bench of seat and fit appropriate sections. Back portion of seat cover is marked for ease of fitting.
2. Tapes should be tied onto framework on reverse side of seat sections, if the back cannot be removed ensure the seat cover is well tucked in between the seat back and the rear parcel shelf.
3. Replace seats and smooth out wrinkles.